GO!me

Instructions & Tips for Use

@accuquilt

@accuquilt

WELCOME TO OUR FAMILY.


Because you purchased the AccuQuilt GO! Me® Fabric Cutter Starter Set, we know you're as passionate about quilting as we are. Welcome! It's safe to say you're excited about saving time, fabric, effort and space. That being said, please keep this handy set of instructions and safety tips for your reference.

Please read carefully to learn how to best use and maintain your new AccuQuilt GO! Me[®] fabric cutter.

NEW TO FABRIC DIE CUTTING?

- Take a little time to get acquainted with GO! Me®. As you develop great diecutting skills, you'll see optimal use of your fabric.
- Check the orientation of the lengthwise grain before each cut.
- Practice cutting with scrap fabric.
- Test cut one shape before cutting many shapes to ensure fabric orientation is correct.


How to operate your GO! Me® cutter



1. Place.


Layer die (with foam side up), fabric and cutting mat.

For most accurate cuts, place cotton fabric on the lengthwise grain (see page 4). To conserve fabric, cover only shape to be cut, not entire die board.



2. Turn.

Push die, fabric and mat firmly against roller. Roll through cutter.



3. Done!

Remove mat and perfectly cut shapes! Repeat process.

OPERATING INSTRUCTIONS



- Do not allow children to operate unattended.
- Use only with GO! fabric cutting dies.
- Handle foam covered die blades with care.
- Never place anything including extra mats, fabric or shims – under dies while cutting.
- Always use a cutting mat.
 Do not cut into steel roller.
 Doing so will damage dies and void the warranty.

Follow these steps to get perfect cuts every time

- **1. GO WITH THE GRAIN** For most accurate cuts, be sure you're cutting on the lengthwise grain (straight of grain) as the fabric goes under the cutter.
- The lengthwise grain runs parallel to the selvage edge the bound edges of fabric that prevents unraveling or fraying so place your fabric on the die with the selvage edge facing you (or the cutter handle) before running it through the cutter.
- Cutting on the lengthwise grain is particularly important when cutting geometric shapes and Block on Board® dies (aka BOB® or classic dies).
- 2. PRE-CUT FABRIC STRIPS To use the AccuQuilt GO! Me[®] cutter, first pre-cut strips of fabric approximately ½" wider than the shape you want to cut.
- These strips can be layered or fan-folded to cut multiple shapes in one pass.







TIPS: Orient the lengthwise grain to the length of the cutter. Line fabric up just over the edge of the die blade, not the edge of the die board, to conserve fabric.



- 3. SAVE YOUR FABRIC! When laying your fabric on the die, only place it right over the shapes you wish to cut. There is no need to cover the entire board. Two Tone™ Foam makes it easy to align fabric just over the edge of the shape so you can save fabric.
- **4. CUT UP TO 6 LAYERS AT A TIME** The GO! Me[®] fabric cutter cuts a wide variety of fabric in a varying number of layers. Always begin with fewer layers and build up.



MAXIMUM # OF LAYERS




*Cut only one layer with Rag Dies.

FABRIC TIPS

- Cut shapes from fabric remnants and scraps. Great for using up stash!
- For fast appliqué, apply fusible web to fabric then cut.
- Use good quality fabric to reduce fabric stretch.
- We recommend that you test cut your fabric first. AccuQuilt does not take responsibility for fabric cutting errors.

DIE TIPS

- Threads may remain after cutting with some fabrics. Snip with scissors.
- As long as the desired shape is covered, you can use a different size mat than your die board.
- GO! die sizes compatible with GO! Me[®] fabric cutter:



AccuQuilt offers many different die shapes and sizes designed with features to save you time and to give you the most accurate cuts. Visit accuquilt.com to see our wide selection of piecing and appliqué dies to use with your GO! Me® fabric cutter.

GO! DIES DESIGNED TO SAVE YOU TIME




Two Tone[™]
Foam:
Makes it
quick and
easy to align
fabric over
blades so
you can
save fabric



Notches: Line up the notches for accurate cuts and easy piecing of curvy quilt designs



Dog-eared Corners & 1/4" Seam Allowance: More time quilting and no time clipping!



Strip Cutters with Angled Guidelines: Silkscreened guidelines make it easy to align fabric & sub-cut shapes to the sizes you need



Block on Board® (BOB®): Create a complete block with all the shapes on one die board

GO!® CUTTING MATS

GO! cutting mats are specially made for use with GO! cutters.

- Store mats flat and avoid direct sunlight.
- Extend the life of your mat by alternating the sides when cutting.
- Replace mat when cutting performance of die is reduced or mat shows excessive wear.
- Do not use warped mats.



CARING FOR YOUR CUTTER & DIES

For best results, keep your GO! Me® fabric cutter clean and lint-free. To clean the cutter, use a clean, soft, dry cloth. Use canned air to clean lint from rollers. Avoid abrasives, solvents and spray cleaners.

Use a die pick or tweezers to remove scraps of fabric from tight areas between die blades. Use a lint roller to remove lint and tiny scraps from foam side of die. Organize and protect your GO! Me® cutter and dies with AccuQuilt GO! totes and storage racks.

REGISTER ONLINE FOR A FREE SIX-MONTH EXTENDED WARRANTY

Now, when you register online at accuquilt.com/registerproduct, we will extend your warranty by six months. And as a bonus, we'll automatically create an



AccuQuilt MyProduct Library for you, so you can keep track of the AccuQuilt products you own, as well as everything you add to your collection.

Don't wait! Get a FREE SIX-MONTH extended warranty when you register online at accuquilt.com/registerproduct.

GOI

NEED HELP?

AccuQuilt Customer Support available 8 a.m.-5 p.m. CST, Monday-Friday 888.258.7913 accuquilt.com/me

@accuquilt

Find the full line of AccuQuilt® products when you visit accuquilt.com.