
arrow
classic sewing furniture

ASSEMBLY INSTRUCTIONS

MakerBasics™ Sewing Table

ITEM NO.: 31110 White




0LL26E001

the spirit of sewing.


General Assembly Guidelines

1. Read the instructions carefully before beginning the assembly process to ensure proper assembly of this product. Please open and inspect the contents of box(es) to see that all parts and hardware are included.

2. **Tools Required**



3. **Understanding How the Cam Fastener Works**




Screw cam bolts flush as illustrated.

Press cam into hole until flush with surface. The arrow direction must point in the direction of the hole.


Insert bolt through pre-drilled hole in edge of panel.

Turn clockwise to lock cam with bolt.

Tip: place a small bit of WD-40 or similar lubricant into the pre-installed cam bolt holes to help the cam bolts screw in better.



4. **Glue** provided is to secure wood dowels in place and is optional. If glue is used during assembly, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately. It is not necessary to glue the other end of the dowel when attaching to other parts.



Use and Care Your cabinet normally requires a minimum amount of maintenance; however, the following points are worth noting:


Cleaning – To remove marks and enhance the surface, wipe with a gentle all-purpose cleanser. DO NOT use ammonia-based, harsh chemicals or abrasive cleaning agents. Wipe dry immediately.

Electrical and Hydraulic Lifts – Require annual lubrication with WD-40 or similar lubricant.

Parts List: Panels & Hardware


NOTE: Do not attempt to assemble this product alone.

Two people are required.




ITEM	DESCRIPTION	QTY	BOX
A	Top Panel	1	1 of 1
D	Back Panel	1	1 of 1
X	Left Side Panel	1	1 of 1

ITEM	DESCRIPTION	QTY	BOX
Z	Right Side Panel	1	1 of 1
O	Front Panel	1	1 of 1
L	Support Bar	1	1 of 1




c1 6x35 Cam Bolt **x19**




d1 8x30 Dowel Pin **x13**




c2 5/8" Cam Cover **x19**



s5 Feet Pins **x4**




b1 Post Bolt **x4**



L Support Bar



s1 3.5x14 Screw **x16**



s2 Insert Support **x7**



c3 Cover Tab **x4**




a Allen Wrench **x1**


Step 1: Panel Preparation




c1 6x35 Cam Bolt **x19**



d1 8x30 Dowel Pin **x13**



s5 Feet Pins **x4**



Prep the **Panels** shown for assembly.

Attach **c1 Cam Bolts** to **Panels A, X and Z**

Insert **d1 Dowel Pins** into the edges of **Panels D, X, Z and O**

Attach **s5 Feet Pins** to the bottom edges of **Panels X and Z.**

Step 2: Cabinet Sides and Back




c2 ⅝" Cam Cover **x10**

NOTE! You will begin assembling your Sewing Table with all panels upside down.

Begin assembling prepared panels.

Insert **c1 Cam Bolts** on **Panels X and Z** into Cam Locks on **Panels D and O**. Tighten Cam Locks and cover with **c2 Cam Covers**.



Step 3-1: Top




c2 5/8" Cam Cover **x9**

NOTE: This step requires two adults to complete.

Carefully lift the cabinet assembly and lower it down onto **Panel A,** carefully inserting Cam Bolts on **Panel A** into Cam Locks on **Panels X, O, D and Z.**

Tighten Cam Locks and apply **c2 Cam Covers.**

Step 3-2: Top




s1 3.5x14 Screw **x16**

s2 Insert Support **x7**

Insert **s2 Insert Support** pegs into the inside edge of the sewing well, as shown.


Atach **L Metal Support Bar** to **Panels A and O** using **s1 Screws.**



Completed MakerBasics Sewing Table



c3 5/8" Cover Tab **x4**




b1 Post Bolt **x4**



a Allen Wrench **x1**

You may attach your MakerBasics Cutting table to other pieces in the MakerBasics collection using **b1 Post Bolts**, or use **c3 Cover Tabs** to fill in the pre-drilled attachment points.

If you choose to use the **c3 Cover Tabs**, simply push them into the pre-drilled attachment points.



To connect MakerBasics pieces to one another, use the provided **b1 Post Bolts** as shown here.

Tighten with included **Allen Wrench.**

YOU DID IT! **Congratulations! A better sewing experience awaits!**

LIMITED WARRANTY

Arrow Classic Sewing Furniture 10-Year Warranty

WHAT THIS WARRANTY COVERS: Arrow Companies, LLC (Arrow) provides limited warranty coverage to the original purchaser of this product against defects in materials or workmanship of Arrow furniture components for a period of ten years from the date of purchase. As used in this Warranty, "defect" means imperfections in components which substantially impair the utility of the product. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

HOW TO GET SERVICE: Simply contact Arrow at 1-800-533-7347 or CS@ArrowSewing.com. When you request warranty service, you must also present proof of purchase documentation, which includes the date of purchase (detailed receipt), and photos of the product. Arrow will replace any defective part (at its sole option), excluding labor. Replacement parts will be warranted for only the remaining period of the original Warranty.

Replacement parts will be shipped freight prepaid on any initial warranty claim during first year of Warranty only. Warranty applies only to defects confirmed by Arrow Companies, LLC and will be replaced or repaired at Arrow's option. In the event parts are no longer available for a warranty claim, customer may receive brand new cabinet at a price equal to 60% off the MSRP of a current comparable model.

WHAT'S NOT COVERED: There is no Warranty coverage for defects or conditions that result from the following: Failure to follow product assembly instructions, information or warnings; misuse or abuse; intentional damage; fire, flood, alteration or modification of the product; use of the product in a manner inconsistent with its intended use; any condition resulting from incorrect or inadequate maintenance, cleaning, care or neglect; cuts or scratches; caster damage as a result of moving furniture fully loaded or with locked casters; damage resulting from electrical surge or lightning; or use in commecial or education environments. Arrow Sewing Furniture is designed for residential use only.

ARROW SHALL HAVE NO LIABILITY for ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND and all such damages are EXCLUDED FROM THIS WARRANTY, such as loss of use, disassembly, transportation, labor or damage to property on or near the product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. The Warranty cannot be transferred to subsequent owners or users of the product, and it shall be immediately void in the event the product is resold, transferred, leased or rented to any third party or person other than the original purchaser.

ADDITIONAL LIMITATIONS: THERE ARE NO OTHER WARRANTIES APPLICABLE TO THIS PRODUCT. Under the laws of certain states, there may be no implied warranties from Arrow and all implied warranties, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE are disclaimed where allowed by law. TO THE EXTENT ANY IMPLIED WARRANTIES ARE APPLICABLE, ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY or the minimum period allowed by law, whichever is shorter. Some states do not allow limitations on how long an implied Warranty lasts, so the above limitation may not apply to you. This limited warranty gives you specific legal rights. This limited warranty does not, in any way, affect the rights given to you by law.


REGISTER YOUR PRODUCT: Original purchaser should register the purchase online at www.ArrowSewing.com/warranty.

COMPLETE YOUR SEWING STUDIO!

Elevate your sewing experience with Arrow's Best-Selling Accessories!

Custom Sewing Inserts


Enhance your sewing experience with a custom acrylic sewing insert! Custom acrylic sewing inserts are designed to fill the gap between your sewing machine and sewing cabinet's lift opening to create a flush, ergonomic surface for flat bed sewing. To ensure a perfect fit, custom acrylic sewing inserts are built specifically for your sewing machine and sewing cabinet combination. Say hello to happy wrists, straighter stitches, and an elevated sewing experience!



Custom Sewing Insert

Sewing Chairs

Arrow's #1 Rated Height Adjustable Sewing Chair is a must have accessory for your dream sewing room! Cute, comfortable and convenient - our lovable sewing chairs feature vibrant sewing themed patterns, 360° swivel access and lumbar support for long hours at your workstation. Don't look now, but under every seat cushion is a hidden storage compartment to store your notions and patterns! Available in 10 colors to perfectly match your sewing sanctuary!



Height Adjustable Sewing Chair

P.O BOX 410 Elkhorn, WI 53121
1-800-533-7347 Ext. 1
cs@arrowsewing.com
arrowsewing.com